Table of Contents

Dedication iii
Preface xi

Chapter 1: Introduction to STAAD.Pro CONNECT Edition

Introduction to STAAD.Pro CONNECT Edition 1-2
Basic Features of STAAD.Pro CONNECT Edition 1-2
Starting Bentley STAAD.Pro CONNECT Edition 1-2
Starting a New Project 1-4
Working in User Interface 1-6
- Ribbon Tab 1-6
- Tool Search 1-10
- Quick Access Toolbar 1-10
- Workflow 1-10
- Data Area 1-13
- Status Bar 1-13
- View Window 1-14

Keyboard Shortcuts 1-14
Importing and Exporting a Model in STAAD.Pro 1-15
Self-Evaluation Test 1-17
Review Questions 1-17

Chapter 2: Structural Modeling in STAAD.Pro

Introduction 2-2
Structural Modeling Using STAAD Editor 2-3
- Creating Nodes 2-3
- Creating Members 2-7
- Creating Plate Elements 2-14
- Creating Solid Elements 2-16

Structural Modeling Using STAAD GUI 2-18
- Creating Nodes and Members Using Snap Node/Beam Method 2-18
- Creating Plate Elements Using the Snap Node/Plate Method 2-25
- Creating Solid Elements Using the Snap Node/Solid Method 2-25

Structural Modeling Using the Structure Wizard 2-29
- Truss Models 2-30
- Frame Models 2-32
- Surface/Plate Models 2-33
- Solid Models 2-34
- Composite Models 2-35
- Import CAD Models 2-36

Evaluation Copy. Do not reproduce. For information visit www.cadcim.com

VBA Macro Models 2-36
Self-Evaluation Test 2-40
Review Questions 2-41

Chapter 3: Structural Modeling Using Tools

Introduction 3-2
Essential tools for Structural Modeling 3-2
Adding Beams Using Tools 3-2
Creating Collinear Beams 3-7
Creating Beams Along Axes 3-7
Creating Plates Using Tools 3-9
Creating Plates Using Meshing 3-10
Creating Infill Plates 3-12
Creating Solid Elements Using the Add Solid Tool 3-14
Creating a Structure Using the Translational Repeat Tool 3-14
Creating a Structure Using the Circular Repeat Tool 3-15
Shifting Structure Using the Move Tool 3-18
Rotating Structure Using the Generate Rotate Tool 3-19
Mirroring a Structure 3-21
Other Miscellaneous Tools 3-23
Stretching Members Using the Stretch Tool 3-24
Intersecting Members Using the Intersect Tool 3-25
Merging Members and Nodes 3-25
Renumbering Nodes, Members, and Elements 3-26
Breaking Beams at Selected Nodes 3-27
Cutting Sections 3-27
Self-Evaluation Test 3-31
Review Questions 3-31

Chapter 4: Defining Material Constants and Section Properties

Introduction 4-2
Material Constants 4-2
Creating New Materials 4-3
Editing Material Properties 4-4
Assigning Materials to the Structure 4-4
Defining Orthotropic Material 4-5
Section Properties 4-9
Prismatic Section 4-9
Tapered Sections 4-13
Steel Sections 4-15
Steel Joist and Joist Girders 4-18
Plate/Surface Thickness 4-18
Self-Evaluation Test 4-22
Review Questions 4-22

Evaluation Copy. Do not reproduce. For information visit www.cadcim.com

Chapter 5: Specifications and Supports

Introduction 5-2
Node Specification 5-2
Member Specification 5-8
- Release 5-9
- Offset 5-10
- Property Reduction Factors 5-12
- Cable 5-13
- Truss 5-13
- Compression 5-13
- Tension 5-13
- Inactive 5-14
- Fire Proofing 5-14
- Imperfection 5-14

Plate Specification 5-14
- Release 5-15
- Ignore Inplane Rotation 5-16
- Rigid Inplane Rotation 5-16
- Plane Stress 5-16
- Ignore Stiffness 5-16

Supports 5-17
- Fixed 5-18
- Pinned 5-18
- Fixed But 5-18
- Enforced 5-19
- Enforced But 5-19
- Multilinear Spring 5-19
- Foundation 5-19
- Inclined 5-20
- Tension/Compression Only Springs 5-21

Self-Evaluation Test 5-25
Review Questions 5-25

Chapter 6: Loads

Introduction 6-2
Primary Loads 6-2
- Selfweight 6-3
- Nodal Load 6-4
- Member Load 6-5
- Area Load 6-10
- Floor Load 6-10
- Plate Loads Enhanced 6-13
- Solid Loads 6-18
- Temperature Loads 6-19
- Seismic Loads 6-19
- Time History 6-28

Evaluation Copy. Do not reproduce. For information visit www.cadcim.com

Wind Load Enhanced 6-34
Snow Load 6-43
Response Spectra 6-45
Repeat Load 6-52
Frequency 6-53
Load generation 6-53
Defining Vehicle Loading 6-54
Defining Load Combinations 6-62
Defining Load Combinations Automatically 6-63
Self-Evaluation Test 6-65
Review Questions 6-66

Chapter 7: Performing Analysis, Viewing Results, and Preparing Report

Introduction 7-2
Pre Analysis Print 7-2
Problem Statistics 7-3
Joint Coordinates 7-3
Member Information 7-3
Material Properties 7-3
Support Information 7-3
Member Properties 7-3
Element Information 7-3
Solid Information 7-4
All 7-4
Cg 7-4
Performing Analysis 7-4
Perform Analysis 7-5
PDelta Analysis 7-5
Perform Cable Analysis 7-5
Perform Direct Analysis 7-7
Perform Imperfection Analysis 7-7
Perform Buckling Analysis 7-8
Perform Pushover Analysis 7-8
Post Analysis Print 7-8
Load List 7-9
Joint Displacement 7-9
Member Forces 7-9
Support Reactions 7-10
Story Drift 7-10
Cg 7-10
Mode Shapes 7-10
Section Displacement 7-10
Force 7-10
Analysis Results 7-10
Member Stresses 7-11

Evaluation Copy. Do not reproduce. For information visit www.cadcim.com

Element Forces/Stresses 7-11
Viewing Results 7-11
View Output File 7-12
Go to Post Processing Mode 7-13
Preparing Reports 7-21
Self-Evaluation Test 7-31
Review Questions 7-32

Chapter 8: Physical Modeling

Introduction 8-2
Starting a New Project In Physical Modeling 8-2
Modeling 8-3
Using Construction Aids 8-3
Drawing the Structure 8-5
Assigning Model Properties 8-12
Defining Boundary Conditions 8-17
Applying Loads Enhanced 8-19
STAAD.Pro Model Data 8-28
Transferring Physical Model to Analytical Model in STAAD.Pro 8-28
Self-Evaluation Test 8-28
Review Questions 8-29

Index **I-1**

Evaluation Copy. Do not reproduce. For information visit www.cadcim.com